



Pulse Share

PRODUCT MANUAL

3 independent motors

10 pulsation modes

10 massage modes

Remote control

Waterproof

**Made from silicone
and ABS plastic**

Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The glow indicates charging in progress.
- A full charge takes up to 2 hours for 1 hour of play.
- Do not use the device while charging.
- The remote control is powered by 1 AAA battery.



Magnetic USB charging port

How To Use

Without remote control

- Hold the (⏮) button to turn the clitoral attachment on/off.
- Press it quickly to cycle through 10 pulsation modes.
- Hold the (⏮) button to turn the receiver's end on/off.
- Press it quickly to cycle through 10 message modes.
- Hold the (⏮) button to turn the giver's end on/off.
- Press it quickly to cycle through 10 message modes.

Without remote control

- Hold the (⏮) button on the toy to enter the standby mode.
- Press the (⏮) button on the remote to cycle through 10 pulsation modes.
- Hold it to pause the clitoral attachment.
- Hold the (⏮) button on the toy to enter the standby mode.
- Press the (⏮) button on the remote to cycle through 10 message modes.
- Hold it to pause the receiver's end.
- Hold the (⏮) button on the toy to enter the standby mode.
- Press the (⏮) button on the remote to cycle through 10 message modes.
- Hold it to pause the giver's end.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Do not get water inside the remote control as it is not waterproof.
- Use with water-based lube only, no silicone lubricants.

Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.



edenfantasys
THE NEW INTIMACY

www.edenfantasys.com

Customer Service
10 AM - 7 PM EST
Phone: +1 (770) 604 - 1352